

油管扣压参数表

液压油管扣压参数表

胶管内径	胶管钢丝层数	外套代号	外套扣压前直径	外套扣压后直径
6	1SN06	00110-04	20	17.3
	2SN06	00210-04	21.5	18.9
8	1SN08	00110-05	20.9	18.3
	2SN08	00210-05	23	20.5
10	1SN10	00110-06	23.5	20.5
	2SN10	00210-06	25	21.9
13	1SN12	00110-08	27	24
	2SN12	00210-08	28.3	24.8
	4SP12	00400-08	29	26
16	1SN16	00110-10	30	26.8
	2SN16	00210-10	31.5	28
	4SP16	00400-10	32.5	28.8
19	1SN20	00110-12	34	30.5
	2SN20	00210-12	35.6	32
	4SP20	00400-12	37	33.5
25	1SN25	00100-16	42.6	39
	2SN25	00210-16	45	40.5
	4SP25	00400-16	46	41.5
	4SH25	00401-16	46	42
32	1SN32	00110-20	51	47.5
	2SN32	00210-20	55	49
	4SH32	00401-20	53	48.8
38	1SN40	00110-24	58	53.5
	2SN40	00210-24	62.5	57
	4SP40	00401-24	61	56
	4SH40	00401-28	69	64
51	1SN50	00110-32	72	67
	2SN50	00210-32	75	69
	4SH50	00401-32	77	71